

FLEX 2000®

Description PVC material with paper backing for die cut applications.
Average thickness: **250 micron**

Basic information Due to the many different base materials available on the market, the following heat transfer instructions are given as guideline only:
Die cut
Transfer setup
Temperature: **160°C**
Time: **15"**
Pressure: **medium (3÷4 bar)**

Application instructions Mirror die cut the material
Place the material on the garment with its paper backing
Heat apply
Remove the support cold

Suitable textiles Cotton, polyester and blends of these materials
(not suited for treated and dye sublimation fabrics)

Washing instructions Wait **24h** after the heat transfer
80°C Max – inside out
Do not use bleach or other aggressive chemical agents
Dry clean: **no**
Tumble dry: **yes**



Siser s.r.l.

Viale della Tecnica n° 18
36100 Vicenza - Italy
Tel. +39 0444.287960
Fax +39 0444.287959
info@siser.it - www.siser.it

r.e.a. vi 171856 - reg. imp. vi n° 14971
c.s. € 103.300 i.v.- p.iva 01591490246

N.B.

All information given in this sheet are based on our experience.
We always recommend performing a test before starting standard production.
For best results we recommend to store the product away from direct sunlight.

The product meets the Italian and EU regulations relating to its proper use, and to the (EU) regulation n. 1907/2006/EU REACH (Registration, Evaluation, Authorization and Restriction of Chemical substance). This document can be subject to variations. Updated versions are available on our www.siser.it. For further information, please contact our Sales Office. Thank you.