


How to change USB mode?

(Jaguar IV and Puma III LCD series)

Go→ On/Off line → MISC→ Select USB printer type.





(Expert/Sable/Bengal NO LCD series)

1. Press ON/ Offline button
2. Press Pause and Origin Set together.
3. Press Cut Test for Common USB mode, press Data Clear for GCC USB mode

USB mode	Repeat	Data Clear	Cut Test
Common USB mode	●	●	⊙
GCC USB mode	●	⊙	●

4. Press Origin Set to save



