


HOW TO CUT A KATZ DISPLAY BOARD


The best results we achieved were with a static knife, an oszillating knife and with die cutting.
To cut KATZ DISPLAY BOARD only half through the cutting knife must be set on -0.5mm from the bottom of the board.



We use a ZÜND M250 cutter, the setting may vary when using other cutting machines.


HOW TO FOLD A KATZ DISPLAY BOARD

1. Half through Cut: The best results we achieved were with a static knife & an oszillating knife.




2. V-cut: The best results we achieved were with a static knife.

If you want to fold it to the other side to cover the edges you can use this cut.



3. V-cut with gap: For this cut you need a router.

If you want to fold it to the other side to cover the edges or to fold it more than 90° you can use this cut.



The specific settings need to be tested for each machine and thickness.