





Effortless Signage.

APPLICATION INSTRUCTIONS FOR CLINGZ®

ClingZ® consists of a white or clear polypropylene film and a paper or clear PET backer.

Preparation: Make sure the surface is clean and dust free

1. **IMPORTANT:** Remove the backer from the film
2. Apply the graphic, adjust, and smooth with your hands or a felt squeegee
3. To remove, pull away and recycle



ClingZ® is a polypropylene film that clings to any dry surface using an electric charge. The material is not suitable to adhere to fabrics or very porous surfaces. Avoid placing in a drafty location, such as around fans, open doors or vents to maximize its performance.